

Quik Trak

Project information

Job name:	Location:
Engineer:	Date submitted:
Contractor:	Submitted by:
Manufacturer's representative:	Approved by:

Technical data

Material	Wood
Prop 65 label required?	Yes

Product information and application use

Uponor's fully assembled Quik Trak® Panels consist of six panels fastened together with strapping tape and feature aluminum heat-transfer backing. The panels are staggered two inches on both ends to aid alignment. Use with 5/16" Wirsbo hePEX™ tubing only. One package includes six panels.



Part name	Part no.	A [Inch]	B [Inch]	C [Inch]	Weight per UOM [lbs/UOM]
Quik Trak 7" x 48" Panels	A5060701	47.75	6.836	0.482	2.8
Quik Trak 7" x 48" x 6 Panels (fully assembled set)	A5060761	-	-	-	17.46

Installation	Related applications
Place Quik Trak Panels on floor surface, ensuring the seams are staggered. Secure one side of the panel with a screw on each end to allow for quick realignment of panels. After properly placing the panels, secure each one with ten screws (five on each side of the groove). Clean any debris from the panel grooves. Apply a thin, 1/8" bead of 100% silicone Quik Trak Sealant (E6050010) throughout the entire length of the groove. The silicone acts as an adhesive agent, promoting good heat transfer from the tubing to the panel. Install the tubing according to the design. For additional information, refer to the Uponor Quik Trak Installation Manual and the Uponor Radiant Floor Heating Installation Handbook	Radiant Heating and Cooling Systems

Footnotes	Contact information
-	Uponor Inc. 5925 148th Street West Apple Valley, MN 55124 T 800.321.4739 F 952.891.2008 Uponor Ltd. 6510 Kennedy Road Mississauga, ON L5T 2X4 T 888.594.7726 F 800.638.9517