

1830 SERIES TELEPHONE ENTRY EXPANSION

ELEVATOR CONTROL, & ADD ENTRY POINTS



Model 2348
Elevator Control

More doors and elevators? Customize your Access Devices to your space.

The DKS 2348 Elevator Control System provides complete elevator security typically used in high rise condominium, apartment, or office building applications to restrict which floors visitors and building residents have access to.



Model 2358
Tracker Expansion

Model 2358 "Tracker" Expansion Boards are used with Models 1833, 1835, 1837 and 1838 Access Controllers to expand these Systems to control up to 24 entry points.

Wireless Tracker Expansion Boards are used with DKS Models 1833, 1835, 1837 and 1838 to expand these Access Controllers to control up to 24 entry points. Save time, labor and money by connecting Card Readers and Keypads to the 1830 Series Controllers without the need to run wiring from each unit.

