



INSTALLATION INSTRUCTIONS

HAIL GUARDS 1HG0406 / 1HG0407

The Hail Guards **1HG0406 / 1HG0407** are designed to prevent damage to the condenser coil of the unit.

The following parts are required:

- 1 ea. - Top Panel
- 2 ea. - Side Panel
- 1 ea. - Diamond Cut Panel
- 1 ea. - Hardware Package
 - 6 ea. - #10- 16 x ½ Screw
 - 6 ea. - #10- 16 x ½ TEC Screw
 - 1 ea. - Installation Instruction



Rooftop Model	Hail Guard Model	A
ZF180, ZS-15, J15ZF	1HG0406	43
ZF210, 240, 300 ZS-18, -20, -25 J18ZF, 20, 25 XP180, XA-15, J15XP	1HG0407	47

Step 1:

Check for correct model number and number of parts above.

Step 2:

Remove wire guard from unit if equipped.

Step 3:

Take one side panel and align with edge of corner post of unit and use (3) #10- 16 x ½ TEC Screw . Repeat with opposite side panel.

Step 4:

Open the clips on side panels and slide diamond cut panel between flange on side panel and clips. Then close the clips to hold screen.

Step 5:

Then take top panel and slide under unit top and then align holes with side panels and secure.