
**RWT Wall Thimble**


- Provides necessary clearance to combustibles.

Model Number	Size	Dim. A	Length B	Dim. C
3RWT	3"	5 1/2"	3 1/16"	3 9/16"
4RWT	4"	6 1/2"	3 1/16"	4 9/16"
5RWT	5"	7 1/2"	3 1/16"	5 9/16"
6RWT	6"	8 1/2"	3 1/4"	6 9/16"
7RWT	7"	10"	3 1/4"	8 1/16"
8RWT	8"	11"	3 1/4"	9 1/16"

Sleeve is adjustable from 3 1/2" to 6 1/4".





3"-7"



8"-14"

RWB Wall Bracket

- Available in 3" through 14"
- 8" through 14" bracket used with perforated pipe strap supplied by others

**RFS* Firestop Spacer**

- Fits 2x6 wall.
- Available in 4" only.
- For Other firestops see installation instructions.

