

MODEL 975XL

Reduced Pressure Principle Backflow Preventers 1/4" to 1/2"



ITEM NO.	DESCRIPTION	1/4"	3/8"	1/2"
1	BALL VALVE, TAPPED	14-850TM	38-850TM	12-850TM
2	TEST COCK	18-860	18-860	18-860
3	CHECK COVER	971-3-010F	971-3-010F	971-3-010F
4	O-RING, COVER	123N	123N	123N
5	NO.2 CHECK SPRING	951-33	951-33	951-33
6	NO.1 CHECK SPRING	971-33	971-33	971-33
7	POPPET	951-30	951-30	951-30
8	SEAL RING	951-12S	951-12S	951-12S
9	SEAL RING RETAINER	951-14	951-14	951-14
10	RETAINING BOLT	951-11	951-11	951-11
11	POPPET ASSEMBLY	951-300S	951-300S	951-300S
12	CHECK SEAT	951-18	951-18	951-18
13	O-RING, CHECK SEAT	020N	020N	020N
14	BALL VALVE	14-850M	38-850M	12-850M
15	O-RING, RELIEF VALVE SEAT	WK-016N	WK-016N	WK-016N
16	RELIEF VALVE SEAT	971-18	971-18	971-18
17	RELIEF VALVE SPRING	971A-33	971A-33	971A-33
18	RELIEF VALVE RETAINING BOLT	971-11	971-11	971-11
19	RELIEF VALVE SEAL RING RETAINER	971-14	971-14	971-14
20	RELIEF VALVE SEAL RING	971-12S	971-12S	971-12S
21	RELIEF VALVE LOWER PLUNGER	971-34A	971-34A	971-34A
22	RELIEF VALVE DIAPHRAGM	971-43	971-43	971-43
23	RELIEF VALVE UPPER PLUNGER	971-34	971-34	971-34
24	O-RING, RELIEF VALVE STEM	011N	011N	011N
25	RELIEF VALVE STEM ASSY.	971-50S	971-50S	971-50S
26	RELIEF VALVE COVER BOLTS	971-11A	971-11A	971-11A
	RV. & CHECK SEAT TOOL	971-SEATTOOL		
27	RELIEF VALVE COVER	971-3A-010F	971-3A-010F	971-3A-010F

REPAIR KITS

RK14-975XL			RK14-975XLR		
REPAIR KIT COMPLETE MODEL 975XL 1/4", 3/8" & 1/2" Only			RUBBER REPAIR KIT MODEL 975XL 1/4", 3/8", 1/2" Only		
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
951-12S	2	SEAL RING	951-12S	2	SEAL RING
971-12S	1	RELIEF VALVE SEAL RING	971-12S	1	RELIEF VALVE SEAL RING
971-43	1	DIAPHRAGM	971-43	1	DIAPHRAGM
123N	2	O-RING, COVER	123N	2	O-RING, COVER
011N	1	O-RING, RELIEF VALVE STEM	011N	1	O-RING, RELIEF VALVE STEM
971-33	1	NO. 1 CHECK SPRING			
951-33	1	NO.2 CHECK SPRING			
971A-33	1	RELIEF VALVE SPRING			