

Johni-Ring[®] Plus

Specialized wax gaskets for Urinals and
Back Outlet Toilets



Johni-Ring Plus for Urinals

Johni-Ring Plus for Back Outlet Toilets

DESCRIPTION

Johni-Ring Plus for Urinals and **Johni-Ring Plus for Back Outlet Toilets** provide a permanent sanitary seal that is gas and water tight. Constructed of high quality golden wax with a felt core, rings will not dry out, harden or deteriorate. Provides true alignment and can be used on cast iron, copper or plastic fittings. **Johni-Ring Plus for Urinals** has a two-inch diameter that fits most wall hung urinals. **Johni-Ring Plus for Back Outlet Toilets** fit most 4" wall hung and floor mounted toilets.

Both meet Federal Specification TT-P-1563A.

SIZES AND PACKING

Johni-Ring for Urinals

STOCK NO.	SIZE	PACKING	WEIGHT/CASE
90-260	2" Diameter	24	7.0 lbs.

Johni-Ring for Back Outlet Toilets

STOCK NO.	SIZE	PACKING	WEIGHT/CASE
90-270	4" Diameter	24	11.5 lbs.

Specifications

Johni-Ring[®]
Plus

Johni-Ring[®] Plus

Specialized wax gaskets for Urinals and Back Outlet Toilets

APPROVALS AND LISTINGS

Meets Federal Specification TT-P-1536A

SPECIFIC USES

Wax gasket rings for sanitary seal to back outlet toilet drainage fittings and urinals.

SPECIFIC APPLICATIONS*

Designed to work with all types of installations such as cast iron, copper and plastics.

PHYSICAL PROPERTIES

Specific Gravity: .82 - .86
Solubility in water: Insoluble
Appearance and color: Golden wax

WARNINGS OR CAUTIONS

Read all cautions and directions carefully before using this product.

DIRECTIONS FOR USE

Johni-Ring Plus for Urinals: Remove wrapping from wax bowl ring. Place wax ring firmly onto urinal flange. Set urinal firmly against flange and tighten bolts evenly. (Wax ring works best at room temperature.)

Johni-Ring Plus for Back Outlet Toilets: Remove wrapping from wax bowl ring. With bowl On protective pad, have rear side of bowl face you. Place wax ring around outlet opening. Make sure wax ring is firmly in place to assure adhesion. Carefully install toilet to drainage fittings. (Wax ring works best at room temperature.)



MATERIAL SAFETY INFORMATION

FOR MORE INFORMATION ON THIS PRODUCT, REQUEST MATERIAL SAFETY DATA SHEET (MSDS) #68.

For Delivery by Fax	Call 1-800-942-4636
Internet	See MSDS section of www.herchem.com
Mail	Contact Hercules at address below or any Hercules representative

This product is defined as an "article" and is not classified as hazardous in accordance with OSHA 1910.1200.

HMIS Hazard warning 0-1-0-A.

INGREDIENTS	CAS#
Petrolatum	8009-03-8

* For special applications which may not be covered on this or other Hercules literature, please contact Hercules Technical Services Department by phone at 1-800-221-9330 or send a fax to 1-800-333-3456.



Hercules Chemical Company, Inc.

111 South Street, Passaic, NJ 07055-9100

Phone: 800-221-9330 • Fax: 800-333-3456

e-mail: info@herchem.com

<http://www.herchem.com>

